




Nodelocked Licentie

Cloud Enabled licentie

Met een cloud licentie ben je niet meer afhankelijk van een vaste werkplek. Je kunt overal inloggen met jouw licentie, zolang er een internetverbinding is en er Solid Edge is geïnstalleerd. In deze handleiding lees je hoe je jouw nodelocked licentie omzet.

Inhoud

Stap 1 • Licentiebeheer openen	4
Stap 2 • Sold-To selecteren	4
Stap 3 • Cloud Enabled activeren	5
Stap 4 • Gebruikers toekennen en wisselen	6
Stap 5 • License Utility instellen	8
Stap 6 • Solid Edge starten	9
FAQ	11

Inleiding

Met een Cloud Enabled licentie plaats je de licentie in de cloud. Je hebt daardoor een internetverbinding nodig om de licentie te kunnen aanroepen. Je logt vervolgens in met je Webkey account. Hierdoor ben je niet meer afhankelijk van een systeem gekoppelde licentie. In deze handleiding beschrijven we de stappen om jouw Nodelocked licentie om te zetten naar een Cloud Enabled licentie. Je zet de een licentie per Sold-To om. Vallen er meerdere licenties onder deze Sold-To? Je zet deze allemaal om naar de Cloud.

LET OP: een Cloud licentie ondersteunt nog niet alle modules van Solid Edge. Heb je een uitbreiding op jouw licentie? Neem dan eerst contact op met de customer service om te controleren of je deze module via de cloud kunt gebruiken.


Stap 1 • Licentiebeheer openen

- Ga naar de [License management page](#) en log in met jouw webkey account.

Heb je nog geen webkey account of is deze niet bij jou bekend? Volg dan onze handleiding [Webkey account aanmaken](#) om er één aan te maken.

Stap 2 • Sold-To selecteren

- Selecteer de Sold-To van de licentie die je om wilt zetten naar de cloud. Het is namelijk mogelijk dat hier meerdere Sold-To nummers staan.



Select the license management function from below

Emergency Passwords and License Files

Obtain temporary passwords or emergency license files for PLM software products. These will allow you to start your systems for a limited time. Your Customer Service Representative will be notified that you requested this service.

Configuration Report

Display licenses needing to be registered for particular locations and machines.

Sold-To/Install

Display information on record regarding this Sold-To/Install.

Composite Host ID

The Composite Host ID (CID) entry and information page.

Passwords and License Files

Obtain passwords or license files for PLM software products.

Cloud Enabled License

Click here to change your license method from node locked to Cloud Enabled. Cloud Enabled licenses require an internet connection and user login. This change applies to all products on the Sold To/Install.

Product Activation

Click here to activate and maintain your Solid Edge node locked or I-Deas licenses


Bill-To

Display information on record regarding this Bill-To.

Stap 3 • Cloud Enabled activeren

In deze stap zetten we de Sold-To om naar Cloud Enabled. Je converteert hiermee alle licenties die onder het geselecteerde Sold-To vallen.

- Selecteer “Cloud Enabled License” gevolgd door “Confirm”.



Select the license management function from below

Emergency Passwords and License Files

Obtain temporary passwords or emergency license files for PLM software products. These will allow you to start your systems for a limited time. Your Customer Service Representative will be notified that you requested this service.

Configuration Report

Display licenses needing to be registered for particular locations and machines.

Sold-To/Install

Display information on record regarding this Sold-To/Install.

Composite Host ID

The Composite Host ID (CID) entry and information page.

Passwords and License Files

Obtain passwords or license files for PLM software products.

Cloud Enabled License

Click here to change your license method from node locked to Cloud Enabled. Cloud Enabled licenses require an internet connection and user login. This change applies to all products on the Sold To/Install.

Product Activation

Click here to activate and maintain your Solid Edge node locked or I-Deas licenses

Bill-To

Display information on record regarding this Bill-To.

Confirm Switch to Cloud Enabled

By clicking Confirm you are changing your license method to Cloud Enabled licensing. Once this change is made you will need to assign products to Webkey users associated with your install. When you assign products you will have the opportunity to create new Webkey user accounts as needed.

Once you click confirm to change your account back to node locked licensing you will need to contact Siemens via your business partner or customer account representative.

Important note: Only products on active maintenance are available for Cloud Enabled Licensing.



- De opties “Passwords and License Files” en “Product Activation” zijn niet meer van toepassing en vind je ook niet meer terug op de “License management” pagina. Op deze pagina zie je ook direct dat de licentie een Cloud Enabled license is.

Select the license management function from below

Cloud Enabled License

Emergency Passwords and License Files

Obtain temporary passwords or emergency license files for PLM software products. These will allow you to start your systems for a limited time. Your Customer Service Representative will be notified that you requested this service.

Cloud Enabled License

Click here to manage your Cloud Enabled user accounts.

Bill-To

Display information on record regarding this Bill-To.

Sold-To/Install

Display information on record regarding this Sold-To/Install.

Composite Host ID

The Composite Host ID (CID) entry and information page.

Stap 4 • Gebruikers toekennen en wisselen

Het webkey account waarmee je bent ingelogd is ook de Administrator Webkey. Met dit account beheer je de gebruikersrechten. De gebruikers die je in deze stap aanmaakt en die een eigen Webkey krijgen, kunnen geen wijzigingen aanbrengen in de toegekende licenties.

In het volgende scherm zie je alle beschikbare licenties. Zie je niets staan? Ververs dan de pagina. Gaat het om één licentie, dan is deze stap klaar en kun je verder naar [License Utility instellen](#).

- Via “Assign User” ken je de verschillende features toe aan de verschillende gebruikers. Hou hierbij de volgende volgorde aan:
 - De basisfeatures
 - Add-ons

Manage Product Assignments

If you are the only user of this account you should have received an e-mail containing instructions and links to install the new version.

If you have purchased multiple licenses click the **Assign User** action for each item in the table below and follow the instructions to assign the product to a user. Installation and licensing instructions will be sent via e-mail to each assigned user.

Please note that you can assign licenses to users other than yourself but only that user will be able to run the software. To resend the e-mail instructions to the assigned user click **Send instructions** action in the table.

Product	Version	Activation Code	Sold To	Username	Action
Solid Edge Premium					Assign User Send instructions

- Er zijn twee mogelijkheden:
 1. Selecteer de gewenste persoon via het pull down menu en druk op "Assign user"
 2. Maak een nieuwe gebruiker aan. Vul hiervoor de benodigde gegevens in en druk op "Create New Webkey". De aangemaakte gebruiker ontvangt een mail met de uit te voeren stappen.

Manage Product Assignments

Assign Product

To assign the product, select from the list and click "Assign User".

To assign the product to a WebKey that is not yet linked with your account, enter an email, name, and phone number of the user and click "Create New WebKey".

If the email has a WebKey associated with it, the user will receive a welcome email with instructions to install and activate their product.

A new WebKey will be created if one does not already exist and an email will be sent with instructions to complete registration.

Product	Version	Sold To	Username	Assign to:
Solid Edge Premium	1948657		[redacted]@enginia.nl	@enginia.nl (▼) @enginia.nl (▼) @enginia.nl (▼)

[Assign User](#)

New WebKey User:

first_name* last_name*

Email*

☒ company ☐ university ☐ other

organization Country* (▼)


[Create New Webkey](#)

[Terug](#)


- Herhaal de bovenstaande stappen totdat je alle gebruikers en features hebt toegevoegd.
- Met de bovenstaande stappen wissel je ook de licentie tussen verschillende gebruikers.

Stap 5 • License Utility instellen

- Ga naar de Windows startknop en typ “License Utility” (1) in het zoekveld. Klik op het gevonden resultaat (2).




- Selecteer “I am Cloud enabled” (1) gevolgd door “OK” (2).




Stap 6 • Solid Edge starten


- Zorg ervoor dat je een actieve internetverbinding hebt.
- Start Solid Edge.
- Kies in de Solid Edge Cloud Gateway voor "Sign in".



- De browser opent. Vul het e-mailadres van jouw webkey account in (1) in en druk op "Log in" (2).



- Geef het bijbehorende wachtwoord op (1) en druk op "Log in" (2).




The image shows the Siemens ID login interface. At the top, it says 'SIEMENS ID'. Below this is a username field with an 'Edit' button. Underneath is a password field labeled 'Password*' with a red box and a pink circle containing the number '1' around it. To the right of the password field is an eye icon. Below the password field is a link that says 'Forgot password?'. At the bottom of the login section is a large red 'Log in' button with a red box and a pink circle containing the number '2' around it. Below the 'Log in' button is a link that says 'Don't have an account? Sign up'.

- Je ziet de melding dat je succesvol bent ingelogd.

You have successfully signed into Siemens applications

Close this window and return to Siemens applications

- Start Solid Edge via de Solid Edge Cloud Gateway.



FAQ

- Ik zie de optie “Cloud Enabled license” niet terug op de “license management” pagina.
Je maakt op dit moment gebruik van een floating licentie. Dit type licentie kan je niet omzetten naar een Cloud Enabled licentie.
- Er gebeurt niets nadat ik mijn gegevens om in te loggen heb ingevoerd. De “Sign in” knop is daarna ook uitgereijst.
Om de licentie te kunnen controleren, maakt Solid Edge verbinding met de server van Siemens. Hiervoor de klok de juiste actuele tijd aangeven. Pas de tijd aan als deze niet goed is gesynchroniseerd.
- Ik ga weer vanaf een vaste plek werken en zou weer “gewoon” node locked willen werken. Ik zie alleen geen optie om dit om te zetten.
Het omzetten van “Cloud Enabled” naar “Node locked” kan alleen Siemens doen. Mocht je dit willen neem dan contact op met de customer service.

Vragen?

Als je na het lezen van de documentatie twijfels hebt over de procedure, neem dan contact op met onze Customer Service:

- Klantportaal: mijn.enginia.nl
- Telefoon: 085-4891717
- Mail: support@enginia.nl

Neem ook eens een kijkje bij onze [trainingen](#).